

Stainless Theatre Control Panel (sTCP)

Features and benefits



Providing a focal point for the monitoring and control of the operating theatre environment, Starkstrom's unique modular panels offer the following benefits:

- Each modular panel fascia is future proofed at the design stage enabling upgrades to be performed with minimal disruption and downtime.
- Client driven component changes can be easily accommodated during the production stages with minimal cost and delays to production.
- Panels can be customised to clinical requirements.

Standard dimensions for 1, 2, 3, and 4 x-ray screen variants enabling wall apertures to be prepared at an early stage.

1st and 2nd fix configuration enables electrics and wall box to be installed at the building construction stage, whilst the clinical fascia is installed at the 'theatre clean' stage to prevent fascia damage.

Screw-less fastenings ensure a smooth easy to clean fascia surface to IP65.

Dependent upon the theatre layout and configuration, Starkstrom's panels are provided with either front or rear access doors for service and maintenance.

Choice of brushed grain or powder painted stainless steel finish to suit any theatre environment.

Large number of installations worldwide.

Integrated theatre control panels

Contains segregated ventilation compartments for monitors/PACS viewers/computers and keyboards.



www.starkstrom.com

256 Field End Road, Eastcote, Ruislip, Middlesex, HA4 9UW, UK
Tel +44 (0) 20 8868 3732 Fax +44 (0) 20 8868 3736

